

How I mount those starter drives:

1. Squeeze it in a vise like this. At this point you can hold the pin in place positioned thru one wall of the drive while you release pressure on the drive...that will hold the pin in place.



Here, the pin's in place and the drive is ready to slide onto the starter shaft.



2. Line up the pin with the hole...



3. Support the end with a block of something...do NOT use any of the wife's kitchen utensils! Don't ask. BTW, you know where I can buy a nice meat tenderizing mallet? ;=)

OK, here, I've already whacked the pin into place:

